

To choose a combination code and lock door

- Before you lock the door do the following: (door can be either open or closed)
- Ensure the lock handle is pointing to the green mark on the front of the lock.
- Press the BUTTON on the LHS of the lock with your finger.
- To choose your own combination number start with the left hand dial and then following with the other 2 dials, rotate each dial downwards to choose your personal combination number.



- Release the button.
- Shut the door (if not already closed).
- Rotate the lock handle 90 degrees anti clockwise to the red marker on front of the lock.
- **IMPORTANT:** Now rotate (scramble) each dial away from your chosen code.
- The door is now latched and locked.

To Open

- Starting from the left hand dial, rotate each dial downwards and stop at your pre-selected number.
- Rotate the lock handle 90 degrees clockwise to the green mark on front of lock and open the door.